LUDLUM MODEL 44-11 AND MODEL 44-11-1 GAMMA SCINTILLATORS

June 2017

LUDLUM MODEL 44-11 AND MODEL 44-11-1 GAMMA SCINTILLATORS

June 2017



STATEMENT OF WARRANTY

Ludlum Measurements, Inc. warrants the products covered in this manual to be free of defects due to workmanship, material, and design for a period of twelve months from the date of delivery. The calibration of a product is warranted to be within its specified accuracy limits at the time of shipment. In the event of instrument failure, notify Ludlum Measurements to determine if repair, recalibration, or replacement is required.

This warranty excludes the replacement of photomultiplier tubes, G-M and proportional tubes, and scintillation crystals which are broken due to excessive physical abuse or used for purposes other than intended.

There are no warranties, express or implied, including without limitation any implied warranty of merchantability or fitness, which extend beyond the description of the face there of. If the product does not perform as warranted herein, purchaser's sole remedy shall be repair or replacement, at the option of Ludlum Measurements. In no event will Ludlum Measurements be liable for damages, lost revenue, lost wages, or any other incidental or consequential damages, arising from the purchase, use, or inability to use product.

RETURN OF GOODS TO MANUFACTURER

If equipment needs to be returned to Ludlum Measurements, Inc. for repair or calibration, please send to the address below. All shipments should include documentation containing return shipping address, customer name, telephone number, description of service requested, and all other necessary information. Your cooperation will expedite the return of your equipment.

LUDLUM MEASUREMENTS, INC. ATTN: REPAIR DEPARTMENT 501 OAK STREET SWEETWATER, TX 79556

800-622-0828 325-235-5494 FAX 325-235-4672

Model 44-11 and 44-11-1 Gamma Scintillators

TABLE OF CONTENTS

1.	GENERAL
2.	SPECIFICATIONS:1
3.	CALIBRATION1
	Probe Peaking Procedure
	Determining Operating Voltage
PA	RTS LIST4
Mo	del 44-11-1 Gamma Scintillator
	Itage Divider Board, Drawing 2 x 179
	odel 44-11-1 Gamma Scintillator with Signal Splitter
Vo	ltage Divider Board, Drawing 2 x 1805
	odel 44-11-1 Gamma Scintillator
Vo	Itage Divider Board, Drawing 2 x 359
DF	AWINGS AND DIAGRAMS

1. GENERAL

The Ludlum Model 44-11 and M 44-11-1 utilize a Teledyne Integral Detector assembly containing a 2-inch diameter by 2-inch thick NaI (Tl) crystal optically coupled to a photomultiplier tube (PMT). The detectors are compatible with general purpose survey meters, ratemeters, and scalers for highenergy gamma detection (approximately 60 keV to 2 MeV range). The detectors provide high sensitivity for surveying and pulse height discrimination for single channel or multi-

2. SPECIFICATIONS:

channel applications.

The Model 44-11 is available with an optional signal splitter so that two different instruments may be used for high voltage input and detector pulse signal output. For this option, the detector tube socket has two connectors, BNC for the signal output and MHV for high voltage input. "SIG" and "H.V." are silk-screened onto the cover cap for identification of appropriate connections.

VOLTAGE: typically 500 volts to 1200 volts maximum

HIGH VOLTAGE (HV): Variances in HV are due to instrument input sensitivity, cable length, photomultiplier tubes (PMT), and applications

SCINTILLATOR: 5.1 cm (2 in.) diameter by 5.1 cm (2 in.) thick NaI(Tl) crystal

SENSITIVITY: typically 900 cpm/ μ R/hr (¹³⁷Cs gamma)

CURRENT DRAIN: 20 microamps at 1000 volts

PHOTOMULTIPLIER TUBE: 5.1 cm (2 in.) diameter, end window with 10 stage dynode chain at approximately 60 megohms

3. CALIBRATION

Calibration of a Model 44-11 or Model 44-11-1 consists of determination of (1) the resolution of the detector (also called a "probe peaking procedure") and (2) the operating voltage of the detector by "running a plateau." Both procedures are described in the following sections, using a Ludlum Model 2200 as the count rate instrument. A 1µCi 137 Cs check source is used for the peaking **CONNECTORS**: standard series "C" for normal mode; other types available upon request. For signal splitter option, BNC for signal output and MHV for high voltage input.

SIZE:

Model 44-11: 6.4 cm (2.5 in.) diameter by 26.7 cm (10.5 in.) long

Model 44-11-1: 6.1 cm (2.4 in.) diameter by 25.4 cm (10.0 in.) long

CONSTRUCTION: aluminum cap with stainless steel body

HOUSING CONSTRUCTION: 0.051 cm (0.20 in.) aluminum

WEIGHT:

Model 44-11: 0.6 kg (1.4 lbs.) **Model 44-11-1:** 0.9 kg (2.0 lbs.)

procedure, and a calibrated ²⁴¹Am source is used for the plateau procedure.

Probe Peaking Procedure

Energy resolution (probe peaking procedure) is performed to test the integrity of the crystal and tube socket.

Ensure that DISCR control is set so that 1.0 on THRESHOLD dial = 10mV input sensitivity. (If it is not, use a Ludlum Model 500 or equivalent pulser to determine the threshold-versus-millivolt relationship.)

- 1. Set WINDWOW at 0.40 with the WINDOW switched to the "ON" position.
- 2. Set the THRESHOLD dial at 6.42.
- 3. Set high voltage well below 500 V (about 1.10 on HV dial). This ensures that the peaking routine is started below the actual photopeak at 662 keV, and thus does not find a false peak or the 32 keV X-ray peak.
- 4. Set three-position switch (RATE, HV, BATT) to RATE.
- 5. Set range multiplier to X1 and expose the detector to the 137 Cs source.
- 6. Begin increasing high voltage by **slowly** rotating HV dial clockwise.
- Once full-scale deflection is reached, switch range multiplier to X10. Press reset button and continue to increase HV until full-scale deflection is again achieved.
- 8. Switch range multiplier to X100, press reset button, and continue to increase HV.

NOTE: The X100 setting will most often suffice for finding the photopeak, but occasionally the X1K range will be required.

9. Once the peak is located, an increase or decrease in voltage should drop the count rate. If it does not, verify that WINDOW and THRESHOLD are properly set and repeat the above steps. If count rate does drop with an increase or decrease in HV, proceed to confirm peak.

- 10. To confirm probe is peaked, set WINDOW at 1.0 and THRESHOLD at 6.12 (corresponding to 612 keV). Note count rate, then switch window OFF. Count rate should stay approximately the same if probe is peaked. If it is not peaked, count rate will change dramatically.
- 11. Once the peak is confirmed, readjust THRESHOLD dial to 6.42 and WINDOW to 0.40 with WINDOW switched ON.
- 12. Initiate a six-second count and record count rate (and peak HV, if desired).

NOTE: If greater accuracy than Model 2200 kV scale is needed to measure high voltage, disconnect detector and connect a high-impedance voltmeter to a Model 2200.

- 13. Rotate THRESHOLD dial counterclockwise below 6.42 until count rate is approximately half of previous 6-second count.
- 14. Record THRESHOLD dial setting.
- 15. Rotate THRESHOLD dial clockwise above 6.42 until count rate is again approximately half of peak count rate determined in Step 12.
- 16. Record THRESHOLD dial setting.
- 17. Determine the resolution of the peaked probe for ¹³⁷Cs as follows:

$$\frac{FWHM}{H_0} = R$$

where FWHM = width of curve athalf the peak height $H_0 = location of the peak$ centroid (peak energy) R = resolution

Energy resolution is normally expressed as a

Model 44-11 and 44-11-1 Gamma Scintillators

percentage. This, in combination with the terminology used in this procedure, defines the peak resolution as:

U. T. S. - L. T. S. Peak Energy x 100% = R%

where U.T.S. = upper threshold setting L.T.S. = lower threshold setting

EXAMPLE:

- Threshold dial setting (U.T.S.) \cong 6.82 = 5,000 counts in 6-second period (from Step 16)
- Threshold dial setting $\cong 6.42 = 10,000$ counts in 6-second period
- Threshold dial setting (L.T.S.) \cong 6.02 = 5,000 counts in 6-second period (from Step 14)
- $\frac{6.82 6.02}{6.62} \times 100\% = 12.08\%$

The resolution should be less than 13% to be considered an acceptable probe. The value of a new probe should be \cong 8 to 9% and increase toward 13% or more as the probe ages. Any probe with resolution greater than 13% should be considered marginal and sent in for service.

Determining Operating Voltage

NOTE: Plateau HV should be considerably higher than peak voltage (by approximately 200 to 300 volts) if peak routine is performed correctly.

- 1. Connect the detector to the counting instrument.
- 2. Turn WINDOW to OFF.
- 3. Set input sensitivity to 10 mV.
- 4. Select the appropriate range or scale of the counting instrument.

- Expose the detector to the calibration source. (LMI uses ²⁴¹Am, approximately 1.59 μCi in activity.)
- 6. Observing the needle meter deflection or digital readout, find the "knee" of the operating voltage plateau. For a Model 44-11 without signal splitter (and M44-11-1), and if using a Model 2200, both count rate and high voltage (KV scale) can be read on analog meter. For a Model 44-11 with signal splitter, use two instruments - one for HV and one for pulse output. (LMI uses two Model 2200s, with HV disabled on one so as not to interfere with HV input on the other.)
- 7. Observe the voltage reading at the "knee." Round down to the nearest 50 volts. (Example: If knee is at 820 volts, round down to 800 volts. If knee is at 890 volts, round down to 850 volts.) Beginning at this voltage, 6-second count take а for background radiation. Record voltage and count rate. Repeat in 50volt increments until background count rate exceeds 1000 counts in a period (assuming 6-second a 10µR/hr background exposure rate).
- 8. Expose detector to calibration source. Perform and record 6-second source count rates for range of voltages used in step above for background count rates.
- 9. By examination or plotting the data, select an operating voltage that falls approximately in the middle of the plateau. There should be a 50-volt (or greater) buffer on either side of the selected operating voltage.
- 10. Adjust the instrument high voltage to the selected operating voltage.

PARTS LIST

Model 44-11 GAMMA SCINTILLATOR

Ref.	Description	Part No.			
UNIT	Completely Assembled Model 44-11 Gamma Scintillator	47-1541			
* * * * * * * Voltage Divi	Tube Socket Teledyne Integral Detector Assembly Tube Socket Cap Voltage Divider Board HV Wire (White Teflon) Ground Wire Flanged Connector Series "C" 4-40 x 5/16 BH Screws 4-40 x 1/8 Soc Set Screws der Board, Drawing 2 x 179	47-1624 01-5136 2032-027 5002-233 21-9362 21-9432 13-7752 17-8511 17-8531			
Ref.	Description	Part No.			
BOARD	Assembled Voltage Divider Board	5002-233			
CAPACITORS					
C1	0.01µF, 2kV, C	04-5525			
RESISTORS					
R1-R11 R12	4.75 MEG, 1% 10 MEG, 1%	10-7100 10-7102			
MISCELLANEOUS					
	INEUUS				

PARTS LIST

Model 44-11 GAMMA SCINTILLATOR WITH SIGNAL SPLITTER

Ref.	Description	Part No.
UNIT	Completely Assembled Model 44-11	
	Gamma Scintillator with Signal Splitter	47-2157
*	Tube Socket with Signal Splitter	47-1266
*	Teledyne Integral Detector Assembly	01-5136
*	Tube Socket Cap	2032-028
*	Tube Socket Cap Cover	9032-012
*	Voltage Divider Board	5002-247
*	HV Wire (White Teflon)	21-9362
*	Ground Wire	21-9413
*	Screw-in Connector, Series "BNC"	13-7753
*	Screw-in Connector, Series "MHV"	13-7775
*	6-32 x 1/4 BH Screws	17-8518
*	4-40 x 1/8 Soc Set Screws	17-8531

Voltage Divider Board, Drawing 2 x 180

Ref.	Description	Part No.			
BOARD	Assembled Voltage Divider Board	5002-247			
CAPACITORS					
C1 C2-C3-	0.0015μF, 3kV, C NPO 0.01μF, 2kV, C	04-5518 04-5525			
RESISTORS					
R1 R2-R12 R13	1 MEG 4.75 MEG, 1% 10 MEG, 1%	10-7097 10-7100 10-7102			
MISCELLANEOUS					
13 EA.	CONTACT-003-1381-003	01-5245			

PARTS LIST

W2

Model 44-11-1 GAMMA SCINTILLATOR

Ref.	Description	Part No.				
UNIT	Completely Assembled Model 44-11-1 Gamma Scintillator	47-3131				
* * * *	Teledyne Integral Detector Assembly Voltage Divider Board HV Wire (White Teflon) Ground Wire Flanged Connector, Series "C" 4-40 x 5/16 BH Screws	01-5660 5002-571 21-9362 21-9432 13-7752 17-8511				
Voltage Divid	Voltage Divider Board, Drawing 2 x 359					
Ref.	Description	Part No.				
BOARD	Assembled Voltage Divider Board	5002-571				
CAPACITORS						
C111	0.01µF, 2kV, C	04-5722				
RESISTORS						
R001-R004 R011-R013 R5 R101-R104 R111 MISCELLAN	4.75 MEG, 1% 4.75 MEG, 1% 4.75 MEG, 1% 4.75 MEG, 1% 10 MEG, 1%	12-7995 12-7995 12-7995 12-7995 12-7996				
W1	Teflon White #22 wire	21-8893				

22GA JSF22/168-black wire

21-9154

DRAWINGS AND DIAGRAMS

Model 44-11 and Model 44-11-1 Assembly View, Drawing 32 x 36 Voltage Divider Board, Drawing 2 x 179 Voltage Divider Board (Signal Splitter Option), Drawing 2 x 180 Voltage Divider Board, Drawing 2 x 359







